



Community | Recreation | Sports | Business

Intruder Alarm System



Quick Guide

INTRUDER ALARM SYSTEM


Disarming system on entry via remote keypad on lobby wall

1. Unlock entrance door and enter lobby

2. Key in four digit code

3. Zone(s) accessed by code light up


4. Press YES key to disarm alarm **WITHIN 30 SECONDS**



INTRUDER ALARM SYSTEM

Resetting system on exit via remote keypad on lobby wall

1. Make sure that all protected doors, including the door to the Community Room, are firmly closed



2. Key in four digit code

3. Zone(s) accessed by code light up

4. Press YES key to rearm system

5. Exit building and close door firmly WITHIN 30 SECONDS; keep door closed whilst locking.